



Use Polyester Stichbond Fabric at corners and around plumbing after applying the first coat of the waterproof membrane

- Ready for Tile, Plaster, or other Finishes
- First Coat of Waterproof Basecrete
- Fibreglass Mesh
- First Base Coat – Basecrete
- LOGIX ICF as specified. Scuff surface.